




# Adjustable Binder Attachment




1



2



3



## Information

### Purpose

- For binding edges with bias tape widths of 5 – 20 mm (1/4" – 3/4").


### For your safety

Before using this accessory, please read the instruction manual at hand as well as the instruction manual of your machine carefully.

## Application

### Setting the Binder Attachment

- > Feed the bias tape into the presser foot. (Fig. 1)
- > Use the front adjusting wheel (a) to adjust the width of the guide to the width of the bias tape (b). (Fig. 2)
- > Attach the Presser Foot.
- > Check the needle position and adjust it if necessary.
- > If the needle position adjustment options on the machine are not satisfactory, loosen the rear screw (a) on the presser foot and move the tape guide to the left or right (b). Tighten the rear screw. (Fig. 3)



### Sewing on the bias tape

- > Set a straight stitch, a narrow zigzag stitch or a decorative stitch.
- > Sew a few stitches on the bias tape.
- > Place the fabric between the tape halves and push it to the far right.  
(Fig. 4)
- > Sew on the bias tape.