



# Straight Stitch Plate



1



2



## Information

### Purpose

- For straight stitch and free-motion sewing as well as for quilting with rulers.
- For embroidering and CutWork projects.

### For Your Safety

Before using this accessory, please read this instruction manual as well as the instruction manual of your machine carefully.

## Application

### Changing the Stitch Plate

- > Switch off the machine and disconnect it from the power supply.
- > Remove the needle.
- > Remove the presser foot.
- > Lower the feed dog and remove the bobbin cover.
- > Remove the screws of the stitch plate with the screwdriver. (Fig. 1)
- > Remove the stitch plate.
- > Insert the straight stitch plate and tighten the screws with the screwdriver. (Fig. 2)